* 1 : w/ Automatic Light Control, w/ Entry & Start System
* 2 : Except *1
* 6 : w/o Entry & Start System
*10 : S/D, 5-Door H/B
E50(A), E51(B), E52(C), E61(D)
Main Body ECU
* 1 : w/ Automatic Light Control, w/ Entry & Start System
* 2 : Except *1
* 3 : w/ Double Locking
* 4 : w/o Double Locking
* 5 : w/ Entry & Start System
* 6 : w/o Entry & Start System
* 1 : w/ Automatic Light Control, w/ Entry & Start System
* 2 : Except *1
* 5 : w/ Entry & Start System
* 6 : w/o Entry & Start System
* 7 : H/B Automatic A/C
* 8 : Except *7
* 9 : w/ Intrusion Sensor
E75
Theft Warning ECU
Intrusion Sensor
Overhead J/B
A24
Horn